

Main Frame Installation & Operation Manual
Standard 15 Amp System
5, 8 & 12 Zones

MF-5, MF-8 & MF-12

OPERATING INSTRUCTIONS

PAGE – 2	ELECTRICAL LOCKOUT
PAGE – 3	FEATURES
PAGE – 4	INPUT POWER
PAGE – 4	SITE SELECTION
PAGE – 4	ELECTRICAL INSTALLATION
PAGE – 5	POWERING UP
PAGE – 6	SHUT DOWN
PAGE – 6	MAIN FRAME TO MOLD CONNECTIONS
PAGE – 7	ANTI-ARCING FEATURE
PAGE – 7	OPTION – EXTERNAL ALARM FEATURE
PAGE – 8	STANDARD ACCESSORY ITEMS
PAGE – 9	SPECIFICATIONS
PAGE – 10 to 17	DRAWINGS

****Please read these instructions thoroughly before using this system****

IMPORTANT: Make sure the main frame circuit breaker is “OFF” before inserting or removing control modules.

Main Frame Installation & Operation Manual

Standard 15 Amp System

5, 8 & 12 Zones

ELECTRICAL LOCKOUT:

THE ELECTRICAL POWER SOURCE MUST BE LOCKED OUT WHENEVER ANYONE IS WORKING ON THE EQUIPMENT.

Each maintenance person should have a personal padlock, with only one key. When working on any equipment this person should use the padlock to lock out the electrical controls. It is most important that the only available key for the lock be in the pocket of the person who is working on the temperature control equipment. If other persons work on the same equipment, each should use their own different lock at a separate lockout station for the controls of the equipment. Accidental startup of the equipment may have tragic results.

In no case should the removal of or work be performed on the temperature control modules or main frames without following proper electrical lockout procedures.

LIFTING APPARATUS:

Temperature control equipment, like any other type of equipment, requires normal periodic maintenance or relocation if the user is to get the most for the investment in the equipment. One of the most flagrant of safety violations is the use of inadequate and unsafe lifting equipment. The temperature control equipment or parts thereof should be assembled, disassembled and moved with lifting facilities that have the capability of gently and slowly lifting and lowering the equipment or various parts.

WHEN USING A CRANE OR FORK LIFT, OPERATE WITHIN ITS RATED CAPACITY, THE SAFE RATED CAPACITY INCLUDES WEIGHT OF HOOKS, BLOCKS, AND ANY OTHER HANDLING DEVICES, SUCH AS CABLES, SLINGS, SPREADER BARS, ETC. CONSIDER THE WEIGHT OF ALL THESE AS PART OF THE LOAD TO BE LIFTED.

WARNING:

When inserting or removing control modules from the main frame, power must be turned off on both the module and main frame. If the module is inserted or removed while under a load, severe damage will result to both the control module and the main frame. Before replacing the module, the main frame must be inspected for damage by a qualified technician. Damage caused to control module and main frame as a result of improper insertion or removal, will not be covered under warranty.

PLANT SAFETY:

The safety procedures mentioned here do not eliminate all safety hazards found in the area of operation. However, they do highlight some procedures that have been found through long experience to improve safety conditions around temperature control systems. International Temperature Control Inc. welcomes inquiries about other suggested safety procedures for use around their equipment.

OUT OF SERVICE:

When the system is out of service, both the control module and main frame must be turned off.

Main Frame Installation & Operation Manual

Standard 15 Amp System

5, 8 & 12 Zones

International Temperature Control, Inc. Modular 15 amp temperature control systems are designed to accurately manage the temperature of multi-zone applications. In the ITC system, individual temperature control modules are installed in a main frame. Each temperature control module works with one “J” or “K” type thermocouple and one heater in a closed loop system.

WARNING:

In most applications, only one heater element can be used per temperature control module. Current draw can fluctuate dramatically if multiple heater elements are wired together. If heaters are wired in parallel, care must be taken to insure that the total wattage of the heaters do not exceed the modules rating. If multiple heaters are wired in series, the effective wattage of the circuit drops dramatically. The use of more than one heater in a circuit should only be contemplated if a qualified electrical engineer designs the circuit.

It is highly recommended that a qualified electrician perform the input power wiring for this control system.

DESCRIPTION:

Unless otherwise specified, main frames are shipped from the factory wired to accept 208/240vac, 50/60 Hz, 3-Phase, power source. This is a 4-wire arrangement using 3 power wires plus a ground wire. If you are unsure of the voltage available, do not connect input power to this system without clarification as you may cause severe damage to the unit.

Units that will operate from 480vac power source will require a step down transformer to convert 480vac to 240vac before it enters the main frame. If the step down transformer is ordered from International Temperature Control, Inc. it will be pre-wired to the main frame.

SITE LOCATION:

- Location of the main frame is important for proper operation and dependable service.
- Ventilation - The main frame must be located so air can move freely in and out of the housing and must not be exposed to excessive heat (maximum operating ambient air temperature 100° F).
- The main frame must be located to minimize dust, dirt, moisture, vibration caustic vapors and excess heat, as they all have a detrimental affect on the equipment.
- The unit must be positioned so the front and rear are readily accessible for setup, adjustment and service.
- Unit must be placed close enough to the mold so all cables can be conveniently run and connections made without undo strain on cables or connectors.
- Place main frame so it will not be damaged by normal plant activities.

POWER CONNECTION:

All electrical connections and servicing must only be performed by qualified electrical technicians. All electrical connections and servicing must be done in accordance with safe electrical practices. Consult your local electrical code prior to electrical installation. Follow proper lock out & tag out procedures before any work is done on the unit.

On units shipped without a power transformer, it is the user's responsibility to supply proper input power cable.

Main Frame Installation & Operation Manual

Standard 15 Amp System

5, 8 & 12 Zones

Select Proper Power Cable:

ITC normally supplies with the main frame, a cord grip suitable of 8/4 SO cord, rated for 50 amps. It is recommended that a qualified electrical engineer determine the proper cable size for your application.

NOTE: It is recommended that a fused disconnect box be installed. This will provide a convenient means to implement lock out and tag out procedures and completely disconnect all input power to the main frame.

ELECTRICAL INSTALLATION: (Reference enclosed drawing)

WARNING: Never attempt to perform any wiring or service to this unit with the input power cable connected to a power source. Disconnect the input power cable from the power source before attempting any service on this unit.

- Remove the back cover panel from the main frame.
- Strip back approximately 3 inches of the input cables outer jacket.
- Strip back approximately ¼ inch of insulation from each individual lead.
- Insert input power cable through the cable grip located on the side of the main frame. Check to make sure there is no tension on the individual leads. Tighten screw on the cable grip
- Wire the input power cable into the input power terminal block located inside the main frame.
- When connecting the power cable, be sure to attach a proper ground lead opposite the green ground wire on the input power terminal block. Make sure that the ground lead is attached to a good earth ground and test housing to ground.
- Make sure that the input power leads are securely attached to the proper input terminal block and that there are no loose wire strands sticking out of the terminals.
- An input power cord grip is normally supplied with each unit. It is very important that the grip is checked for tightness in the main frame and that the input power cable is secured in the grip so that it cannot be accidentally pulled out.
- After the input power cable had been properly installed in the main frame, securely replace the back cover panel on to the main frame with a screw at each location.
- Connect the input power cable to a 240vac service disconnect box (3-Phase for 3 & 6 zone systems and 1-Phase for 1-zone systems) and attach leads to the fused side of the switch. Check to make sure disconnect box is off before opening the box. The ground lead must be attached to a good earth ground and checked.
- Install appropriate size fuses in the main disconnect service box.

WARNING:

All three power leads on three phase systems are electrically hot to ground. Wiring errors at either end of the cable can make the metal enclosure electrically hot and extremely hazardous. Make sure ground is properly and securely attached. Test connection to earth ground.

NOTE: Exposed electrical leads can cause shock or electrocution. Do not connect, apply power or operate when any cover is open, removed or electrical connection is exposed.

POWERING UP:

1. Turn "ON" external power fused disconnect switch to provide power to main frame.
2. Turn "ON" main frame by pushing up on the circuit breaker handle on the front of the main frame. Phase indicators (L1, L2 & L3) will light up, indicating which leg has power. If any of the phase indicator lights do not come on, turn off the power to the main frame and contact a qualified electrical technician.

Main Frame Installation & Operation Manual

Standard 15 Amp System

5, 8 & 12 Zones

3. Whenever the main frame is powered up, make sure the cooling fan is working. You should be able to feel a substantial amount of air being expelled from the fan louvers on the right side of the cabinet. The bottom of all main frames must be free from obstructions to allow air to enter freely. If air flow to the unit is impeded, it could cause premature failure to the main frame or control module.
4. Turn "ON" the individual temperature control modules by depressing the power button on the bottom of the module face plate.

NOTE: Prior to operating system thoroughly read and understand the operating manual for the module being used.

WARNING:

When inserting or removing control modules from the main frame, power must be turned OFF on both the module and main frame. If modules are inserted or removed while under a load, severe damage can result to both the control module and main frame. Damage caused to control module and main frame as a result of improper insertion or removal, will not be covered by warranty. Before replacing the module, the main frame must be inspected for damage by a qualified technician.

NOTE: It is recommended that a fused disconnect box be installed. This will provide a convenient means to implement lock out & tag out procedures and completely disconnect all input power to the main frame.

TO SHUT SYSTEM DOWN:

1. Turn "OFF" each individual module
2. Turn "OFF" main frame by pushing down on the circuit breaker handle on the front of the main frame.
3. Turn "OFF" the external power disconnect box.

MAIN FRAME TO MOLD CABLE CONNECTIONS:

POWER CONNECTORS: Multi-pin (female) power connectors are built into left side of standard main frame to interface with the mold power cable.

THERMOCOUPLE CONNECTORS: Multi-pin (male) thermocouple connectors are built into the left side of standard main frames to interface with the mold thermocouple cable.

THERMOCOUPLE CABLES: Individual mold thermocouple cables are the same as used in our standard 15 amp systems, (Connector on main frame end {female} & connector on mold end {female}).

- Caution must be taken so that power and thermocouple cables are installed in the proper connectors.
- Standard ITC main frame connectors and mold cables are engineered to reduce the possibility of inadvertent installation of the power cable into the main frame thermocouple connector or the thermocouple cable into the main frame power connector. Still caution must be taken to ensure proper installation.
- Reference enclosed drawing for standard power and thermocouple wiring arrangement.
- Temperature control module in main frame zone #1 location will control heater in mold cavity #1, etc.
- Connect power and thermocouple cables to main frame and mold. Firmly set retaining latches to prevent the cables from pulling out of the connectors. Reference enclosed drawing for description of installation.

INSERTING AND REMOVING MODULES:

1. Inserting or removing modules while module and main frame is on could expose the operator to dangerous electrical power. It could also destroy the module and damage the main frame

Main Frame Installation & Operation Manual

Standard 15 Amp System

5, 8 & 12 Zones

2. Turn "OFF" the module and main frame. Lock out & tag out power to the main frame prior to removing or installing temperature control modules.
3. To insert a module, first line up the top and bottom of the card with the card guides located on the top and bottom of the slot.
4. Push module gently, but firmly into main frame card guides until it is fully seated in the edge connector located at the back of the main frame.
5. To remove a module from main frame, grasp the handle and gently, but firmly pull straight out.

CAUTION:

Install Main Frame Blank Plates (MFBP) over any empty slots. **NEVER** operate the system with an uncovered slot, since it will expose you to dangerous electrical power which can cause severe electrical shock.

WARNING:

When inserting or removing control modules from the main frame, power must be turned OFF on both the module and main frame. If modules are inserted or removed while under a load, severe damage can result to both the control module and main frame. Damage caused to control module and main frame as a result of improper insertion or removal, will not be covered by warranty. Before replacing the module, the main frame must be inspected for damage by a qualified technician

ANTI-ARCING FEATURE

This temperature control system is equipped with our innovative **Anti-arcing** feature that will help prevent damage to the control module and main frame in the event the module is inadvertently removed under load. This feature should not be considered a substitute for proper handling procedures, but rather a supplemental protection mechanism.

If an ITC control module is inserted into a main frame not equipped for **Anti-arcing**, the instrument will not provide power to the heater and a "tOh" error code will be displayed. If this condition occurs, the **Anti-arcing** jumper can be moved from the #2 & #3 enabled position to the #1 & #2 disabled position. By repositioning the jumper in the **Anti-arcing** disabled position, the module will function in main frames not equipped with the **Anti-arcing** feature. **Disabling the anti-arcing feature can void your two-year warranty in the event the module is removed from main frame under load, as a resulting in damage to printed circuit board traces.**

NOTE: This feature will only work with ITC's updated TC-2000 main frames, and should not be considered a substitute for proper handling procedures. Disabling the anti-arcing feature could void your two-year warranty if damage occurs.

NOTE: The **Anti-arcing** feature will not prevent damage if the jumper is not in the enabled position.

NOTE: The **Anti-arcing** feature of this module will not prevent damage if the module is used in a main frame not properly equipped for **Anti-arcing**.

ITC main frames manufactured prior to March 2000 were not equipped with the **Anti-Arcing** feature. They can be upgraded with **Anti-Arcing** by installing Contact (MF-ECC) in position #3 of Card Edge Connector (MF-EC). Please consult the factory. (*Refer to the enclosed Anti-arcing sheet for more information.*)

OPTIONS:

EXTERNAL ALARM OPTION:

The External Alarm Option gives the user the ability to have an Audible or Visual alarm located away from the main frame to better alert the operator.

International Temperature Control Inc.
2415 E. Huron P. O. Box 805
Au Gres, MI 48703
Ph: (989) 876-8075 Fax: (989) 876-6640
December 20, 2007

Main Frame Installation & Operation Manual

Standard 15 Amp System

5, 8 & 12 Zones

NOTE: To function, the Optional External Alarm Feature must also be present on the UATC-20C Modules.

The alarm will activate if any of the properly optioned UATC-20C modules in the main frame go to an error condition (regardless of the audible ALARM setting in the Options Menu) activating alarm contacts within the main frame.

The Optional External Alarm Contacts are rated for:

- 10 Amps at 125 VAC, or
- 5 Amps at 250 VAC, or
- 5 Amps at 30 VDC

Connector:

- The contacts are located on pins #1 & #2 of the 5 pin connector (1Z-FC) mounted on the main frame. Use cable end connector (1Z-FE) to plug into connector (1Z-FC) on the main frame.

Main Frame Installation & Operation Manual

Standard 15 Amp System

5, 8 & 12 Zones

SPECIFICATIONS:

Voltage:	208 to 240vac, three phase
Frequency:	50/60 Hz
Maximum Amperage per Zone:	15 Amps
Over Current Protection:	50amp 3-leg circuit breaker with phase indicator
Physical Configuration:	Modules plug in for easy interchangeability
Compatibility:	Compatible with "G" Series Controllers
5-Zone Main Frame Size:	9" High x 14-1/4" Wide x 11-1/2" Deep
Weight:	15 pounds approx.
8-Zone Main Frame Size:	9" High x 20-1/4" Wide x 11-1/2" Deep
Weight:	15 pounds approx.
5-Zone Main Frame Size:	9" High x 28-1/4" Wide x 11-1/2" Deep
Weight:	15 pounds approx.
Construction:	Welded Aluminum
Special Features	Anti-Arching capability with proper ITC module

Main Frame Installation & Operation Manual

Standard 15 Amp System

5, 8 & 12 Zones

MAIN FRAME TO MOLD CONNECTOR

Before connecting the control system to the mold make sure that all mold wiring is correct and that no wires are pinched or shorted to the mold. Check heater wiring for proper resistance between heater wires and from heater wires to mold at the connector. Check for proper thermocouple polarity at the connector. This should be done prior to setting the mold as well.

When connecting the mold interface cables, disconnect the control system input power cable from the power source to prevent possible electric shock. This is important for your own protection.

When mating connectors make sure that you have the proper match. Check to make sure none of the pins are bent or misaligned. You should never have to force connectors together; properly mated connectors will fit together easily.

The power connectors on the mold should be wired following the same pattern as the power connectors on the main frame. Standard mold power connectors are supplied with 6-inch leads that are numbered according to the zone number. These leads should be butt spliced to the corresponding heater wires on the mold. It is very important that these wires are firmly spliced together.

Standard mold thermocouple connectors are physically different from the other connectors. This is to prevent improper connections of power and thermocouple connectors. Thermocouple connectors are also different from each other depending on the number of zones required. All thermocouple connectors follow the same basic wiring pattern with pin #1 being positive (white wire) connection for zone #1 and the opposite pin in the second row being the negative (red wire) connection for zone #1. Pin #2 is the positive connection for zone #2 and the opposite pin in the second row is the negative connection for zone #2. All subsequent zones follow this pattern.

Main Frame Installation & Operation Manual


Standard 15 Amp System

5, 8 & 12 Zones



INTERNATIONAL TEMPERATURE CONTROL, Inc.

STANDARD CONNECTOR KITS



CONNECTORS / CONNECTOR KITS (4-48 ZONE, 10/15 AMP; 2-5 ZONE, 30 AMP)

REF. LETTER	DESCRIPTION	CATALOG NUMBER(S)
A	MOLD THERMOCOUPLE CONNECTOR – 5 ZONE	MTC – 5
	MOLD THERMOCOUPLE CONNECTOR – 8 ZONE	MTC – 8
	MOLD THERMOCOUPLE CONNECTOR – 12 ZONE	MTC – 12
B	MOLD POWER CONNECTOR – 5 ZONE	MPC – 5
	MOLD POWER CONNECTOR – 8 ZONE	MPC – 8
	MOLD POWER CONNECTOR – 12 ZONE	MPC – 12
C	MOLD CABLE END KIT – THERMOCOUPLE – 5 ZONE	MEK – 5TC
	MOLD CABLE END KIT – THERMOCOUPLE – 8 ZONE	MEK – 8TC
	MOLD CABLE END KIT – THERMOCOUPLE – 12 ZONE	MEK – 12TC
D	MOLD CABLE END KIT – POWER – 5 ZONE	MEK – 5PR
	MOLD CABLE END KIT – POWER – 8 ZONE	MEK – 8PR
	MOLD CABLE END KIT – POWER – 12 ZONE	MEK – 12PR
E	FRAME CABLE END KIT – THERMOCOUPLE	FEK – TC
F	FRAME CABLE END KIT – POWER	FEK – PR
G	MAIN FRAME THERMOCOUPLE CONNECTOR	FCK – TC
H	MAIN FRAME POWER CONNECTOR	FCK – PR
I	CARD EDGE CONNECTOR (MOLD TO MAIN FRAME)	AMP – CR

International Temperature Control Inc.
 2415 E. Huron P. O. Box 805
 Au Gres, MI 48703
 Ph: (989) 876-8075 Fax: (989) 876-6640
 December 20, 2007

Main Frame Installation & Operation Manual

Standard 15 Amp System

5, 8 & 12 Zones




INTERNATIONAL TEMPERATURE CONTROL, Inc.

MAIN FRAME WIRING

The standard main frame connector wiring schematic for TC- 2000 Control Systems is shown below. Some units that are special ordered may have different connectors and wiring schematic.


STANDARD MAIN FRAME CONNECTOR WIRING



International Temperature Control Inc.
2415 E. Huron P. O. Box 805
Au Gres, MI 48703
Ph: (989) 876-8075 Fax: (989) 876-6640
December 20, 2007

INTERNATIONAL TEMPERATURE CONTROL, INC.

WIRING DIAGRAM FOR ITC TC-2000
RUNNERLESS MOLDING SYSTEM



International Temperature Control Inc.
2415 E. Huron P. O. Box 805
Au Gres, MI 48703
Ph: (989) 876-8075 Fax: (989) 876-6640
December 20, 2007

Main Frame Installation & Operation Manual


Standard 15 Amp System

5, 8 & 12 Zones




INTERNATIONAL TEMPERATURE CONTROL, Inc.


MOLD THERMOCOUPLE CONNECTOR



MOLD THERMOCOUPLE
CONNECTOR



MOLD THERMOCOUPLE
CONNECTOR



MOLD THERMOCOUPLE
CONNECTOR

International Temperature Control Inc.
2415 E. Huron P. O. Box 805
Au Gres, MI 48703
Ph: (989) 876-8075 Fax: (989) 876-6640
December 20, 2007

Main Frame Installation & Operation Manual


Standard 15 Amp System

5, 8 & 12 Zones



INTERNATIONAL TEMPERATURE CONTROL, Inc.

MAIN FRAME WIRING SCHEMATIC



International Temperature Control Inc.
2415 E. Huron P. O. Box 805
Au Gres, MI 48703
Ph: (989) 876-8075 Fax: (989) 876-6640
December 20, 2007

Main Frame Installation & Operation Manual

Standard 15 Amp System

5, 8 & 12 Zones




INTERNATIONAL TEMPERATURE CONTROL, Inc.

STANDARD

208 – 240 VAC, 3 Phase, 4 – Wire

Delta or “Y” Power Distribution System



As shown above, each module is powered from one of the three phases. Module (1), for example, is powered from phase 1, which is supplied by L1 and L2. Module (2) is powered by phase 2, which is supplied by L1 and L3. Module (3) is powered by phase 3, which is supplied by L2 and L3. **NOTE:** At this point, the sequence repeats itself. For example, Module (4) is connected the same as Module (1) to L1 and L2; Module (5) is connected the same as Module (2) to L1 and L3; Module (6) is connected the same as Module (3) to L2 and L3. Module (7) will be connected to the same phase as Module (1) and (4), etc. This method of connection assures the greatest likelihood of line balance.


International Temperature Control Inc.
2415 E. Huron P. O. Box 805
Au Gres, MI 48703
Ph: (989) 876-8075 Fax: (989) 876-6640
December 20, 2007

Main Frame Installation & Operation Manual
Standard 15 Amp System
5, 8 & 12 Zones



INTERNATIONAL TEMPERATURE CONTROL, Inc.

MAIN FRAME CONTROL MODULE CONNECTOR
AMP - CR




International Temperature Control Inc.
2415 E. Huron P. O. Box 805
Au Gres, MI 48703
Ph: (989) 876-8075 Fax: (989) 876-6640
December 20, 2007

ORDERING INFORMATION


ITC MAIN FRAMES (15 AMP. MAX)

The configurations illustrated below provide wide selection of zone capacities to suit most control application. The 1, 2, 5, 8 and 12 zone frames (MF1, 2, 5, 8 and 12) use individual frame sections. The 16 thru 48 zone frames use 2, 3 or 4 frame sections rigidly fastened together into one prewired integral unit which requires only one main AC power input connection. The Current Voltage Monitor option will be factory installed, when ordered at the same time as Main Frame. Control modules, cables, mold connectors and other accessories are to be ordered separately. (see chart on following page)

MAIN FRAMES (Supplied with 75 Amp, 3 Phase circuit breaker)



STACK FRAMES (Supplied with 75 Amp, 3 Phase circuit breaker)




WORLDWIDE WIRING CAPABILITIES

Unless otherwise specified, all ITC Main Frames will be supplied to accept 240 VAC, 3 phase, 4 wire, 50-60 Hz input power. Wiring diagram (included) illustrates the variety of other voltage, phase and load balancing arrangements possible, such as: (380-415 V, 3 phase, 5 wire, 50-60 Hz), (208-240 V, Single phase 3 wire, 50-60 Hz) and (110-120 V, Single phase, 50-60 Hz). These wiring adjustments can be performed in the field to suit the requirements of the application, or, if specified at the time of original order, ITC will supply the required Main Frame.



INTERNATIONAL TEMPERATURE CONTROL, INC.



- Each frame section has its own cooling fan and protective shield.
- Multi-section frame heights are multiple of 9" height shown (e.g. MF36 is 27" high).
- Main AC input shown will always be in bottom frame section. For higher power requirements, individual power inputs and circuit breakers can be factor installed in each section of a stack frame on aspecial order basis.



CATALOG NUMBER	WIDTH (W)*
MF1 & MF2	7
MF5	14 1/4
MF8 & MF16	20 1/4
MF12	28 1/4
ALL OTHERS	28 1/4

* Does not include connectors.

NOTE: Combination frames to accommodate both 10/15 & 15 amp modules, with or without communication capability are available on special order. Contact ITC.



International Temperature Control Inc.

2415 E. Huron P. O. Box 805

Au Gres, MI 48703

Ph: (989) 876-8075 Fax: (989) 876-6640

December 20, 2007