

# Save, Load, View



You can view the File Operations Page via the **setup** dialog.

Any user can access the File Operations Page, but most functions require that you first log on as the Supervisor.

Operator \*test.efi\* 🧕 30/04/2013 15:08:11

## Accessing the File Operations Page

From the home screen or the main run-screen, in monitor-mode or run-mode, press the setup button, then the "Save Load & View" icon..



This takes you to the File Operations Page.

Nearly all file operations can be performed here, with the exception of importing zone names and adding a new language pack.

- Load Setup files
- View Diagnostics reports
- View the controller Logs
- Export Setup, Diagnostics, Logs and History files
- Import Setup and Diagnostics files
- Delete Setup and Diagnostics files

### **About VISIONS 3000 Files**

The controller loads and saves it's data to/from two sources: the internal drive and an external USB drive. When loading or saving files internally, the user is restricted on the location the files can be placed. For example, the controller decides where setup files should be stored so the user only has to choose a name. When saving or loading files to/from the USB drive, the user can usually choose where on the USB drive the files should be loaded from or saved to.

In this example, the user is importing a setup file from a USB drive and is only permitted to choose a name for the file; there is no list of folders:



129700	o. ofi	0 50700	o ofi	0.000	ition OMar	ifolds of	O in of	6
150Zone.en 0 Suzone.en			ORDA	nuesomai	moids.en	O lighthox efi		
30Cav3Man3Water.efi 🔾 70Cav2Man.efi				O defaults.efi			O Russian_Prob.efi	
0 40Cav41	Man4Water.efi	O 8cav4r	nan10water.efi	O Detij	p-X0124.e	efi	O test.ef	1
•								
ocation: Inter	mal Drive				File		150Z	one4Water
q	w	e	r t	У		•	1	0 P
a	s	d	r	9	h	j	k	<u> </u>
Escape	z	x	c	v	b	n	m	Dele
							123	3 Ente

In this example, the user is exporting a setup file and is permitted to choose the folder on the USB drive as well as the filename:

Folders: EFI-History-150Zone4Water hotrun				Files	Files:				
				150Zone4Water.efi					
Location: USB	Location: USB Stick			File				test .e	
q				t y u i o				Р	
	5	d	1	9	h	L	k	1	
Escape	z	x	c	v	ь	n	m	Delet	
Shift	Caps Lock			Space			123 #@	Enter	
Enter a na	me for the file	or calest	an existing	file to ove	rurite				



The list of files and folders are from the USB drive.



The list of files is from the internal drive.



Save Setup:

Only the Supervisor can access this function.



Most of the options which are configurable in the setup dialog, zone setpoint changes and a few other configurable options, are stored in setup files internally. An ITC controller setup filename ends with the ".efi" suffix.



The setup file currently in use is displayed on the status-bar.

If the filename has asterisks either side of it, the setup has been changed. This is your reminder that the file should be saved.

Changes to the setup file will not be lost if the controller is turned off - the next time the controller is started it will load the current setup file with changes, and the filename will be shown on the status-bar with asterisks.

Selecting "Save Setup" allows the setup to be saved. You can select a new filename (it's like the "Save As" option you are probably familiar with from desktop applications).

You will not be able to choose the folder to save to, because this operation acts on the internal drive.



# Delete Setup and Delete Diagnostics

Only the Supervisor can access this function.

These options allow you to manage the setup files and diagnostics reports stored internally on the controller. Choose the file you want to delete from the list of available files.



You will not be able to choose the folder to save to, because this operation acts on the internal drive.



Load Setup:

The Setter or Supervisor can access this function, but only if the controller is stopped (i.e.: from the home page).



The controller will reconfigure itself from the setup file selected from the list of files stored internally.





Any user can access this function.

Choose from the list of available diagnostics reports stored internally on the controller. The text-viewer dialog appears:

Diagnostics Report	
Started : Fri Mar 22 2013 12:05:15	-
Zone 1 'Tip-1' (Cavity):	
Starting temperature: 23°C. End temperature: 28°C	
Time taken: 21 seconds.	
Heater 1 connected to thermocouple 1 Up. Zone is OK.	
Heater resistance: 12 Ohms	
Zone 2 'Tip-2' (Cavity):	
Starting temperature: 24°C. End temperature: 30°C	
Time taken: 19 seconds.	
Heater 2 connected to thermocouple 2 Up. Zone is OK.	
Heater resistance: 12 Ohms	
Zone 3 'Tip-3' (Cavity):	
Starting temperature: 23°C. End temperature: 29°C	
Time taken: 17 seconds.	

The diagnostics report gives more information than is available in the diagnostics page, and can be viewed any time. The diagnostics report files are simple text files which can be exported to a USB drive for later use on a desktop computer.



Any user can access this function, which takes the user to the Event Logs Page.



**Export Files** 

Only the Supervisor can access these functions.

To export any files, first insert a USB drive into the top-box USB port of the controller.

Select the function you require (export setup, diagnostic, logs or data history).

Exporting logs is simply a case of selecting a name for the log file and a folder on the USB drive where it should be saved to.

The log-file generated is a simple text file. One year's-worth of log messages can create a very large file many megabytes in size.



If you choose to export the setup files, diagnostic reports or data history, you are asked if you want to export all of the files or just one of the files.



If you want to export all of the files in one operation, the controller will place the files in the root folder on the USB drive. You will not be prompted to overwrite files which are already there.

If you export a single file, you can choose the folder on the USB drive to save the file to.

### **About History Files**

History files are very large spreadsheet files which you can open in a desktop PC spreadsheet application. These files of tabled data are extracted from the minute-by-minute data logs held internally on the controller.

Internally, the controller maintains a database for each setup it knows about. When exporting the data, a folder is created on the USB drive for each one of these setups and the spreadsheet files are created in that folder.



If you select to export all of the controller's history database, you will create many folders on the USB drive and will generate a lot of data. One year's worth of data history can require a gigabyte or more of data and will take several seconds to export.

Supervisor You will see a progress indicator on the status bar during long file operations.





**Import Files:** 

Only the Supervisor can access these functions.

Select the folder on the USB drive and the file to import, then choose the name the file should be called once it is imported, or just accept it's current name.

If you choose to import a setup file, the controller will ask you if you also want to load the setup file as the current configuration. If you answer yes to this question, the controller will immediately reconfigure itself to the newly imported setup file.





You cannot import log files or history files, which are specific to this controller. When these files are exported, they are not saved in the same format as they are stored internally.



This feature allows you to select an alternative language for the VISIONS 3000 software. Every displayed object is translated, as well as new log entries and diagnostic reports. Language packs also contain a translated help system. It is possible to import a new language, if provided by ITC.



# Import Language:

The file provided by ITC is called a "Language Pack". Place this file on a USB drive and insert it into the USB port on the back of the top-box. Then click the "Import Language" icon.

You will be asked to select a language pack file from those found on the USB drive



Select Language Pa Language Packs on USB St	ck to Import	Ŷ
Folders:	Files:	Cancel
		Select
File:	LangPack.lpk	

One language pack file can contain multiple languages. You will be asked to select one of the languages to import.



The language packs are checked before being installed. Any problems are displayed and are probably due to data corruption during download or when copied to the USB drive.



International Temperature Control Inc. 2415 E. Huron—P.O. Box 805 Au Gres, MI 48703 USA Tel: (989) 876-8075 Fax: (989) 876-6640 E-Mail: sales@itc-controls.com